

Electric
Convection Oven

Manual

You are welcome to buy our products, the company mainly in the production of western kitchen equipment, and its supporting products include grilled series, fryer series, barbecue series, warmer series, snacks series and so on.

In order to make full use of the performance of this product, reduce unnecessary loss and damage, please read the product manual carefully before use, and properly save for future reference.

Warning:

1. People who have defect about physical, sensory or mental, or lack of experience and knowledge (including children), this specification does not apply.
2. The manufacturer does not comply with the operating instructions for the damage or fault does not bear any responsibility.

HEB series Electric Convection Oven products is absorption design of the advantages of similar products at home and abroad and, with novel styles, reasonable structure, convenient operation, fast heating speed, uniform temperature, energy-saving features. For in the cinema, shopping malls, supermarkets and other traffic places.

I . Basic Parameter

MODEL	ITEM NAME	POWER	DIMENSION
HEB-4F	Electric Convection Oven	2.6KW	595x600x580mm
HEB-8F	Electric Convection Oven	6.4KW	835x760x580mm

II .Transportation and Storage

In the transport process in the furnace should handle with care, not upside down, to prevent on product outer casing and internal damage. Should be placed in a well ventilated warehouse without corrosive gas.

III.Safety Position and Precautions

1. This product should be placed in a stable place, left and right side to leave the non combustible material 10cm above, the back should be from the non combustible material (such as brick wall, etc.) 20cm above.
2. The power supply voltage of the equipment must be in conformity with the power supply voltage of the product power brand.
3. The user needs to be installed in the vicinity of the equipment suitable for the power switch, fuse and leakage protection devices, switches in front of no debris, easy to operate.
4. Before the equipment is used, it must be safely grounded.

5. Before starting the machine should check whether the electrical components of the connection is firm, safe grounding is reliable.
6. Replace the cable with the same type of cable, and replace the professional personnel.
7. The electrical connection of this product installation and maintenance, should please hold electrician operation certificate of the installation.

IV. Instructions

1. Connect the power, turn the timer switch, the temperature control at 200 degrees, about 10 minutes (for the first time use, please clean with hot water, 200 heat for about 30 minutes, remove any smell of insulation)
2. Open the door handle food inside, and then close the door, temperature controller is adjusted to the required temperature, the time needed to adjust the timer (food is put into the oven, the distance between pan and pan at least 40mm, so that air circulation).
3. When the oven reaches the set time, it will automatically stop working.

Warm tip: when the operation, please wear gloves, so as not to burn

V. Cleaning and Maintenance

1. In the cleaning and maintenance should be cut off the power supply, and wait for the equipment to cool to prevent the occurrence of accidents.
2. Open the door, remove from oven, and put them in the water and detergent clean.
3. Clean the oven with the non corrosive cleaning agent and the wet towel. It is forbidden to wash the water directly. In order to prevent the infiltration of water into the performance of the electrical equipment, the electric safety accident is caused.
4. Dry towel to wipe stove
5. After cleaning, please turn on the power and temperature to 80 DEG C, waiting for the furnace dry after the power supply is cut off

VI. Warranty Clause

1. Product is valid for six months.
2. One of the following circumstances shall not carry out the three package, and shall carry out a reasonable charge for repairs.
 - A. More than period
 - B. No valid Notes
 - C. Card content and product does not match the real identity, or altered
 - D. Not caused by the use of man-made damage
 - E. The damage caused by force majeure
 - F. Factory for product failure, not negative in addition to the protection of the indemnity liability.

The products such as user fault cannot be ruled out, to our factory or contact the dealer resolved within six months after sales repair free of charge. Where not by the use of the provisions of the manual wiring, improper use, transport collision damage, need to replace parts of the product, the factory only to recover the costs.

(The specification is subject to change without notice)